

Elite+ data


Contents






Connecting to data

Installing pre-terminated data assemblies




At the back of the module, remove 4x screws and remove rear plate.



Feed data cables through side slots in Elite+ fascia.

Feed the data cables of the pre-terminated data assemblies through front face of Elite+ module.




Screw the rear plate back in place. Torque of 0.6Nm advised.

Connect to the data source. Use cable management for safety.



Mounting (under desk)



Cable tray/basket

Place module in cable

tray/basket and secure

with suitable fixing

devices if possible.

Lift up the shutter on

the front of the RJ45

sockets and insert the


To source

data connectors.

Mark hole positions and drill pilot holes. Fix with suitable screws. Do not over-tighten fixings.


Connecting to data (continued)

Installing data cables



Push in gently until the connectors click into place. Use cable management for safety.





Fit keystone blanks into unused data apertures to prevent dust ingress (supplied separately).

Additional Information

_Safety

- Installation is to be carried out in accordance with relevant Health & Safety regulations and only to be carried out by a skilled or competent person.
- Product to be used only for the intended purpose of distributing data in office and commercial • environments.
- Do not misuse, dismantle or re-configure the product because doing so will invalidate the warranty. •

Standards _____

Refer to the Declaration of Conformity.

Further Guidance

- Should the supply cable need replacing, contact CMD.
- Keystone blanks are supplied separately. For supply details contact CMD.

CLICK

click into place if fitted

correctly.

Product Care

- Clean using a dry cloth. No abrasives or solvents to be used on the product. •
- Do not drop or expose to moisture.





