

Overview: This instruction assumes that the in-floor product elements have already been installed and that the floor covering has been laid (See Stage 1 installation guide.)







Please read this installation guide carefully and ensure that you have all of the components you need to complete the relevant stage of the installation.

Installing the flush lid and trim






Note that the grommet can be installed in two orientations on the floor mount, offering 180° difference in the position of the entry aperture.




Align the keyhole details with the fixing screws and lower the grommet into floor



Locate the fixing screws in the keyhole details then rotate the body clockwise.



Loosen the two fixing screws 5 turns. Do not remove the screws completely!




Fully tighten both fixing screws to secure the grommet in place.

Adjusting the trim height with spacer rings




If the lip of the trim is not exactly flush with the floor surface, the height can be fine-adjusted by removing or adding spacer rings. Carefully remove the grommet body and the two fixing screws, then remove or add the rings as required. (Take care not to drop the screws into the floor void.)



Align the arrowhead on the spacer ring with the arrowhead on the mount to ensure correct installation position.

Then carefully re-insert the fixing screws and re-install the grommet (Take care not to drop the screws into the floor void.)




Additional spacer rings are available to order from CMD for adjusting the height of the trim as shown in steps 6-8. 1mm thick spacer ring: Part No. PSSG00A05. 2mm thick spacer ring: Part No. PSSG00A06.

CM

Lid operation







Fit the grommet lid, ensuring it locates against the internal step detail.

The lid cover can be rotated to adjust the size of the aperture...

Installing cables and conduit (pass-through configuration)





Lift up the lid and rest on the floor to the side of the grommet.

Feed the desired cables or conduit through the grommet and under the floor.



...or to close it


completely.


Fit the lid back in place with the cable/conduit sitting in the entry aperture.

Tap-off engagement/release

WARNING


An unterminated tap-off MUST NEVER be connected to a live track. Provided that it is off load, a terminated tap-off may be removed/ inserted into a live track. Conduit must be bonded to Earth.





backwards until button

clicks upwards to lock.




ton to disengage. Push

forwards and lift up to


remove.

Align tap-off pins with slots on socket. Push down to engage.

Inserting plugs (socket hive configuration)



Lift out the lid and place to the side. Insert the plug into the socket as shown.



With the socket inserted, carefully put the lid back into the grommet.



The cable should feed out of the lid, allowing the lid to sit flush with the grommet.

Additional information

Safety

- Installation is to be carried out in accordance with relevant Health & Safety regulations and only to be carried out by a skilled or competent
 person.
- It is recommended that this product is not installed in high traffic areas.
- The product should be installed to comply with the relevant national standards and be inspected and tested prior to being put into service (in the UK BS 7671 Wiring Regulations).
- Isolate the supply before installation or repositioning. Any locking mechanisms must be used and fully engaged.
- Incorrect use could lead to risk of electrocution.
- Product to be used only for the intended purpose of distributing power in a commercial environment.
- Ensure to replace the lid after use.
- Do not misuse, dismantle or re-configure the product because doing so will invalidate the warranty.
- If a product incorporates RCD protection, the RCD should be regularly tested in-line with current standards.

Standards _

• Refer to the Declaration of Conformity.

Further guidance .

Should the supply cable need replacing, contact CMD.

Product care _

- Clean using a dry cloth. No abrasives or solvents to be used on the product.
- Do not drop or expose to moisture.

